

## Table of Contents, Key to Symbols

Why Use Focal Point?	7
Key to Symbols	8
Table of Contents	8
Product Information	9
Adhesive	10
Crown & Cornice Moulding	12
Polystyl™ Mouldings	22
Chair Rails, Casings, Friezes & Bases	23
Panel Mouldings	26
Medallions	28
Rosettes	36
Rims	37
Domes and Decorative Domes	38
Niches & Niche Caps	40
Door Systems	44
Stair Brackets	47
Corbels	48
Shelves	49
Wall Accents	50
Product Index	54



NEW product



Available in  
FocalFlex™



Part of the  
ProCollection  
(top selling  
products)



Suitable  
for indirect  
lighting



Suitable for  
direct lighting



Available by  
UPS shipping



Compatible  
with Moulding  
Blocks



Medallion  
without  
center hole



Made from  
low-density  
material  
(Polystyl™)


# WELCOME TO FOCAL POINT

For interiors or exteriors, Focal Point products have the workability of white pine. Our virtually maintenance-free products feature deep, crisp, impeccable details and add value to any home. Plus, builder-friendly, single-piece designs reduce installation time and minimize callbacks.

# PRODUCT INFORMATION

## FocalFlex™ Radius Guide


This flexible polymer conforms to curved surfaces to give a seamless look to radius areas when a moulding is used.



Outside Radius



Inside Radius



Arch Radius


License Number	Minimum Outside Radius	Minimum Inside Radius	Arch Radius
11002	6'	5'	n/a
11022	7'	6'	n/a
11042	6'	5'	n/a
11122	7'	6'	n/a
11312	9'	10'	n/a
11340	6'	5'	n/a
11142	8'	7'	n/a
11162	5.5'	4.5'	n/a
11172	7'	6'	n/a
11182	9.5'	8'	n/a
11202	12'	10'	n/a
11272	11'	9'	n/a
11282	8'	6.5'	n/a
11322	10'	11'	n/a
11332	8'	7'	n/a
11372	17'	18'	n/a
11522	1.5'	1'	3'
11602	5'	5'	7'
11612	4'	4'	7'
11662	5'	5'	7'
13002	12'	10'	n/a
13042	1'	1'	4.5'
13072	12'	10'	n/a
13082	3'	2.5'	n/a
14012	4'	3'	n/a
14052	5.5'	4.5'	n/a
15012	2'	1.5'	2.5'
16352	6'	5'	n/a
16362	6'	5'	n/a
16372	6'	5'	n/a
16382	6'	5'	n/a
16392	6'	5'	n/a
16562	1.5'	1.5'	3'
16582	2'	2'	4'
16592	2'	2'	4'
17012	1.5'	1.5'	3.5'
17042	10'	8'	n/a

Call about FocalFlex if not listed here in chart.  
Most products available in any radius.

## Installation Tips

- Miter the corners and use butt joints for straight runs
- Dimensions, table and blade angles and installation guides for available products are on our website
- Use Focal Point Adhesive 3 on corners, mitered joints and butt joints. On large profiles, adhesive can be used on bedding edges where mouldings meet walls and ceiling.
- Lengths should be cut 1/4" longer to allow "springing" of moulding into place
- Moulding is primed and ready to finish. Paint (latex or oil based), stain (non-penetrating gel stain), glaze or faux finish.
- Nail holes and joints can be filled with vinyl spackle, sanded and primed if needed


## FocalFlex™ Materials

Flexible profiles are custom made for your project. A  icon on the moulding page indicates that products are available in Focal Flex™ Materials. Your application and moulding selection will determine which material (either pliable/flexible or pre-formed rigid) can be used. Our Focal Flex materials can accommodate both convex and concave surfaces as well as your arch radius applications. Only a select number of profiles are available in pliable material (see the pliable material chart on this page). Most profiles can be ordered to your specification in rigid material. Please call for pricing and information regarding which material suits your application.

## Fire-Rated Products

Focal Point offers most profiles in a fire-rated material. Our fire-rated products offer the same design detail as our standard products, plus the added assurance of Class-1 fire-rated compliance for International Residential and Building codes. Fire-rated profiles are custom made for your project. Please call for pricing and information.

## Polystyl™

A  icon on page 22 indicates that product is made from a low density polymer material. These products offer affordable design options. Use water-based adhesive caulk with Polystyl™ products.

## Warranty

Focal Point Architectural Products, Inc. warrants its products to be free of any defects in material or craftsmanship for a period of one year from the date of purchase. This warranty does not cover damage resulting from misuse, improper handling, faulty installation, or normal wear and tear. The company's liability is limited to replacement of product found to be defective and does not include labor, transportation cost, damage or other expenses of any kind incurred in connection with the purchase or use of these Focal Point Products.

# PRODUCT INFORMATION

## How To Estimate Required Footage Of Product

- 1) Measure perimeter of room.
- 2) Add 2' for each corner and pattern matches.
- 3) Round to the next standard length.
- 4) One tube of adhesive is needed for every 60' of moulding.

### Example Shown

*This Room Has Four Corners*

Length times two

$$12' \times 2 = 24'$$

Width times two

$$16' \times 2 = 32'$$

Total Length plus Width


$$24' + 32' = 56'$$

Add 56' (+ 2' x 4 corner)

$$56' + 8' =$$

**Total product needed: 64'**

Divide total linear footage by length of moulding. Round up to determine number of pieces needed.



### Adhesive 3

Part #	Description
33333	Single tube
33324	Case/24 tubes



## Preparation

Focal Point® polyurethane products, like wood, will expand and contract due to temperature or humidity changes. The product must be acclimatized to normal room conditions for 24 hours prior to installation. This will allow the product to expand or contract as it adjusts to the climate, thereby preventing movement after installation.

Concrete slabs and unfinished sheet rock may add moisture to the jobsite. Running a heater or air conditioner will help to dehumidify the space.

Moulding should be stored flat. Nothing should be stacked on top of Focal Point products.

## Installation

Begin your installation in the least visible corner of the room and work around the room so that you return to the same corner. (Ending your job in the most inconspicuous corner will prove beneficial if your last cut results in a less than perfect pattern match). If the moulding has multiple patterns, match the larger patterns first. Mouldings should be mitered for Inside and Outside corners (Table/Blade recommendations are available on our website). A compression butt-joint should be used along straight runs at the job site. Compression butt-joints are accomplished by cutting the moulding slightly longer (approx. ¼" over a 12' piece) than the space intended on the wall. After polyurethane adhesive has been applied to contact surfaces, attach each end of the moulding (causing a slight outward bowing) apply pressure to the center of the moulding. This should snap the moulding flush against the wall. Add mechanical fasteners, such as screws or nails, to secure the moulding to your wall. (Refer to finishing section for information regarding touching up the surface)

## Finishing

Focal Point products are factory primed and ready to finish. They may be painted, stained, or faux finished. Fill screw or nail holes using a vinyl spackle or plastic filler. If the primed finish has been scratched or damaged, the area should be spackled, sanded, and touched up with primer prior to painting.

Focal Point recommends a quality latex or oil-based paint for a smooth solid finish. If you are preparing a faux finish, including woodgrain, use a non-penetrating glazing stain or paint. DO NOT use lacquer based paint products on Focal Point products.

## Adhesive

Focal Point Adhesive 3 is specially formulated to be used on polyurethane moulding joints and seams. It welds pieces together when properly used, virtually eliminating call-backs for joint separation. Use one tube of adhesive for every 60 linear feet of moulding. Immediately remove excess adhesive that bleeds on to the face of the moulding.

**NOTE:** PL Premium Polyurethane Construction Adhesive is the only recommended suitable alternative. Our warranty hinges on the use of Focal Point Adhesive 3 or PL Premium Polyurethane Construction Adhesive.

ADHESIVE SHELF LIFE IS 1 YEAR FROM MANUFACTURED DATE, STAMPED ON EACH TUBE.

## historical gallery

*Our licensed historical collections preserve the detail of architectural history and integrity. Logos of the historical societies are used in our product catalog to denote our licensed collections.*

*The symbols below are placed next to products that have been licensed by the corresponding historical society .*

*Williamsburg®*



**National Trust  
for Historic  
Preservation**

### *Products featured :*

**Colonial Williamsburg:** Powell Hallam Chair Rail, License Number 16160; **Victorian Society:** Mille Fleur Crown Moulding, License Number 19240; **Frank Lloyd Wright:** Midway Gardens Frieze, License Number 19520; **Historic Natchez:** D'Evereux Frieze, License Number 13080; **National Trust:** Oatlands Composite Crown Moulding, License Number 17050.

# PRESERVING A PIECE OF AMERICANA

## *Colonial Williamsburg Foundation*

The restoration of Williamsburg, the 18th Century capital of the Virginia colony, was supported by John D. Rockefeller, Jr., from the 1920s to the 1950s. During restoration, he learned that mouldings played a role in the social hierarchy of a home. The degree of detail was an indication of the owner's wealth. It is from the colonial homes and buildings of Williamsburg that Focal Point presents a unique line of colonial mouldings, endorsed by the Colonial Williamsburg Foundation.

## *Victorian Society In America*

On the heels of the colonial era came 19th Century, or Victorian Design. Once reserved only for the wealthy, elaborate ornamentation became available due to craftsmen arriving from Europe - craftsmen "schooled" in fine wood carving and ornate plastering. Elegant and flamboyant, these mouldings and medallions reflect the architecture loved by Queen Victoria, of 19th Century England.

## *Frank Lloyd Wright Collection*

Frank Lloyd Wright's career spanned more than 70 years, and his work revolutionized the architecture of the 20th century. With focus on organic architecture – a natural link between mankind and the environment, which should reflect the individual needs of the client – Wright changed the very way buildings are designed and built today.

## *Historic Natchez Foundation*

In the years prior to the Civil War, Natchez was a thriving community of northern planters who employed European craftsmen to build their homes. French, English, Spanish and West Indian design elements were combined to create a distinctive collection of mouldings, doorways and medallions. During the Civil War, Natchez became the Union Army's command center, protecting the homes from destruction. Today, Natchez represents the largest collection of pre-Civil War homes in the United States.

## *National Trust For Historic Preservation*

From Woodlawn, a Virginia plantation given to Nelly Curtis by her father, George Washington, to Woodrow Wilson's home in Washington, D.C., the properties of the National Trust for Historic Preservation span centuries of architecture and design. Saved from destruction in the 19th and 20th centuries, the homes represent the design elements most popular in North America today.



## Distinctive Mouldings

Memorable mouldings guide the eye and stir the spirit. They elevate rooms from mundane to marvelous.

*Products featured at right:*

A. Polystyl™ Crown  
License Number 10180

B. Regence Cove Crown  
License Number 11400




# CROWN AND CORNICE MOULDINGS

## What is a Profile?

The sample profile to the right shows how a moulding appears from the direct side view, or profile. This view depicts how much area the moulding will take at the point where walls and ceiling meet.

The larger the profile measurement, the more area is taken by the moulding.



## Miter-Free Decorative Blocks

From function to art form, our blocks connect mouldings and accentuate design. They install easily and coordinate with select moulding profiles.

To Install, Simply:

- Fasten blocks and connectors to wall.
- Cut moulding at a 90° angle (1/4" longer than space).
- Use adhesive on moulding ends.
- Snap moulding into place between corner and connector block.
- Secure moulding to wall with nails or screws.

### Connector Blocks



	F	
21625	4 1/8"	UPS
21610	5 7/8"	UPS

### Inside Corner Blocks



	F	
21615	4 1/8"	UPS
21600	5 7/8"	UPS

### Outside Corner Blocks



	F	
21620	4 1/8"	UPS
21605	5 7/8"	UPS

See page 4 for an example of installed blocks

# Crown and Cornice Mouldings

Linden Cornice

13000



	F	H	P	R	L		
13000	8 3/4"	6 3/4"	5 1/16"	7 1/16"	12'		

Cavetto Lucia

19260



	F	H	P	R	L		
19260	9 7/8"	7"	7"	-	12'		

Randal

11770



	F	H	P	R	L		
11770	12"	11 1/4"	4 1/8"	-	12'		

Cove

14010



	F	H	P	R	L		
14010	3"	2 1/6"	2 1/6"	-	12'		

Peyton Randolph Crown

16300

16350



	F	H	P	R	L		
16350	6 1/2"	4 1/4"	5 1/16"	-	12'		
16300	11"	7 1/4"	8 1/16"	-	12'		

Governor's Palace Cove

16360

16310



	F	H	P	R	L		
16360	6 1/2"	5"	4 9/32"	-	12'		
16310	10 5/8"	8 1/4"	7"	-	12'		

Capitol Hill Scotia

19270



	F	H	P	R	L		
19270	7"	3 3/4"	6"	-	12'		

Oatlands Fluted

17020



	F	H	P	R	L		
17020	8"	4"	7 1/4"	-	12'		

Zoller Cove

11280

11180



11290 11300

	F	H	P	R	L		
11280	6"	4 1/4"	4 1/4"	-	12'		
11180	8 7/8"	6 3/16"	6 3/16"	-	12'		
11290	12 3/8"	8 3/4"	8 3/4"	-	12'		
11300	20"	14 1/4"	14 1/4"	-	12'		

St. James

11170

11270

11370




	F	H	P	R	L		
11170	6 1/4"	4 11/16"	4"	-	12'		
11270	9"	7 7/16"	6 1/8"	-	12'		
11370	17 3/4"	13 3/4"	11 1/4"	-	8'		

# Crown and Cornice Mouldings

**Meyer May House**

**19530**



	F	H	P	R	L		
19530	8"	7 7/8"	1 1/2"	-	12'		

**Frank Lloyd Wright Home and Studio**

**19550**



	F	H	P	R	L		
19550	8"	8"	3"	-	12'		

**Franklin**

**23900**



	F	H	P	R	L		
23900	4 1/2"	3 3/16"	3 3/16"	-	8'		

**Holland Cove**

**10670-8**



	F	H	P	R	L		
10670-8	4 1/2"	3 1/8"	3 1/8"	-	8"		

**Belgian Cove**

**10650**



	F	H	P	R	L		
10650	5 1/2"	3 1/8"	4 1/2"	-	6' 6"		

**Monte Carlo**

**10700**



	F	H	P	R	L		
10700	6 5/8"	5 1/8"	4 1/8"	-	6' 6"		

**Santa Fe**


**11650**



	F	H	P	R	L		
11650	11"	6"	8 3/4"	-	12'		

**Taos**

**11640**



	F	H	P	R	L		
11640	8"	5 7/16"	5 1/16"	-	12'		

**Rope Crown**

**23620**



	F	H	P	R	L		
23620	5 7/8"	3 15/16"	3 1/2"	3/4"	8'		

**Tuscany Crown**

**10710**



	F	H	P	R	L		
10710	6 7/8"	4 15/16"	4 3/4"	-	6' 6"		

# Crown and Cornice Mouldings

**Maryland**



	F	H	P	R	L	
11330	6"	4 3/8"	4"	1 1/16"	12'	

**11330**

**Governor's Palace Fretwork**



	F	H	P	R	L		
16320	9 7/8"	7 5/8"	6 1/4"	1 1/8"	12'		
16370	5 3/4"	4 13/16"	3 13/32"	3/4"	12'		

**16320 16370**

**Roman Dentil Crown**



	F	H	P	R	L		
10510	4 3/4"	3 3/8"	3 3/8"	1 5/16"	6' 6"		

**10510**

**Nicolson House**



	F	H	P	R	L		
16340	11"	7 1/4"	8 5/16"	4 1/4"	12'		
16390	6 3/4"	4 1/2"	5"	2 1/2"	12'		

**16340 16390**

**Concord Dentil**



	F	H	P	R	L		
23130	4 1/8"	2 7/8"	2 3/4"	1 3/4"	8'		

**23130**

**Darwin D. Martin House**



	F	H	P	R	L		
19510	8"	7 7/8"	2 1/2"	1 1/2"	12'		

**19510**

**Colonial Dentil**



	F	H	P	R	L		
11580	10 1/4"	7 7/8"	6 5/8"	3"	12'		

**11580**

**Raleigh Tavern**



	F	H	P	R	L		
16330	9 1/2"	6 5/6"	7"	1 5/8"	12'		
16380	5 3/4"	3 7/8"	4 3/16"	1"	12'		

**16330 16380**

**Concord Dentil Crown**



	F	H	P	R	L		
23600	5 7/8"	4 1/2"	3 3/4"	2 1/16"	8'		
11540	5 7/8"	4 1/2"	3 3/4"	2 1/16"	12'		

**11540**

**23600**

**Stanton Hall**



	F	H	P	R	L		
13010	11 1/4"	8"	8"	5"	12'		

**13010**



# Crown and Cornice Mouldings

**Egg & Dart Crown**

**11120**



<b>11120</b>	<b>F</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>	
	5 3/4"	5"	2 7/8"	1 7/16"	12'	<b>FLEX</b>

**Classic Rosette**

**11020**



<b>11020</b>	<b>F</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>	
	5 3/4"	5"	2 7/8"	1 7/16"	12'	<b>FLEX</b>

**Egg & Dart Crown**

**10530**



<b>10530</b>	<b>F</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>	
	6 7/8"	4 15/16"	4 3/4"	1 5/8"	6' 6"	<b>UPS!</b> <b>FLEX</b>

**Glenburnie**

**13020**



<b>13020</b>	<b>F</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>	
	11"	7 1/2"	8 1/2"	3"	12'	<b>UPS!</b> <b>FLEX</b>

**Classic Egg & Dart**

**23135**



<b>23135</b>	<b>F</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>	
	4 1/8"	2 7/8"	3 1/4"	1 1/2"	8'	<b>UPS!</b> <b>FLEX</b>

**Classic Egg & Dart**

**23610**



<b>23610</b>	<b>F</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>	
	5 7/8"	4 1/2"	3 3/4"	1 1/2"	8'	<b>UPS!</b> <b>FLEX</b>

**Egg & Dart Crown**

**11160**



<b>11160</b>	<b>F</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>	
	4 1/8"	3 1/4"	2 9/16"	1 1/2"	12'	<b>FLEX</b>

**Palladio**

**11720**



<b>11720</b>	<b>F</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>	
	7 1/2"	6"	4 1/2"	2 5/8"	12'	<b>FLEX</b>

**Egg & Dart Crown**

**11310**



<b>11310</b>	<b>F</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>	
	8 3/8"	6 1/2"	5 3/8"	2 3/4"	12'	<b>FLEX</b>

**Brussels Crown**

**10550**



<b>10550</b>	<b>F</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>	
	6 7/8"	4 3/4"	4 15/16"	13/16"	6' 6"	<b>UPS!</b> <b>FLEX</b>

# Crown and Cornice Mouldings

**Acanthus Leaf**

**14050**



	F	H	P	R	L
14050	4"	3 3/16"	2 1/2"	2 3/8"	12'

**FLEX**

**Corinthian Crown**

**23155**



	F	H	P	R	L
23155	5 7/8"	4 1/2"	3 5/8"	3 3/8"	8'

**UPS FLEX**

**Georgian**

**11040 11320**



	F	H	P	R	L
11040	6"	4 3/8"	4 3/16"	3 7/16"	12'
11320	9 3/16"	6 7/8"	6"	5 1/4"	12'

**Pro FLEX**

**Shell & Bellflower**

**11140 11340**



	F	H	P	R	L
11140	8 1/2"	6 13/16"	5"	2 1/2"	12'
11340	6"	5 1/16"	3 3/4"	2"	12'

**Pro FLEX**

**Acropolis Crown**

**23125**




	F	H	P	R	L
23125	4 1/8"	3 1/8"	2 1/2"	2"	8'

**UPS FLEX**

**Candler**

**11130**



	F	H	P	R	L
11130	8 1/4"	6 7/8"	4 3/4"	4 3/4"	12'

**FLEX**

**Athenian Leaves**

**23145**



	F	H	P	R	L
23145	4 1/8"	2 5/8"	2 5/8"	2 5/16"	8'

**UPS FLEX**

**Old English**

**11000**



	F	H	P	R	L
11000	5 1/2"	4 3/8"	3 3/8"	10 1/2"	10'

**FLEX**

**Wilson House**

**17040**



	F	H	P	R	L
17040	8"	6"	5 1/4"	2 9/16"	12'

**National Trust for Historic Preservation FLEX**

**Regence Cove**

**11400**



	F	H	P	R	L
11400	8"	6 3/8"	5 1/2"	1 5/16"	12'

**FLEX**

# Crown and Cornice Mouldings

**Oatlands Composite**

**17050**



17050 | F 9" | H 5 7/8" | P 6 3/4" | R 4 5/8" | L 12' |

**Ivy Leaves**

**19230**



19230 | F 7" | H 4" | P 6 1/8" | R 6" | L 10' |

**Carter Composite**

**16600**



16600 | F 5 3/8" | H 3 9/16" | P 3 15/16" | R 4 1/2" | L 8' |

**Carter Composite**

**16610**



16610 | F 7 3/8" | H 4 7/8" | P 5 9/16" | R 5 5/8" | L 8' |

**Provence Crown**

**10560**



10560 | F 9 1/2" | H 8 11/16" | P 3 15/16" | R 12 15/16" | L 6' 6" |

**D'Evereux Cornice**

**13070**



13070 | F 6" | H 4 3/4" | P 4" | R 2 1/2" | L 12' |

**Verona Crown**

**10570**



10570 | F 2 7/8" | H 2 9/16" | P 1 3/16" | R 2 11/16" | L 6' 6" |

**Dauphine Crown**

**10580**



10580 | F 3 1/4" | H 3" | P 1 3/8" | R 12 15/16" | L 6' 6" |

**Rococo Crown**

**10600**



10600 | F 6 3/8" | H 5 7/8" | P 2 3/8" | R 10 3/16" | L 6' 6" |



# Crown and Cornice Mouldings

David Wright House

19500



	F	H	P	R	L	
19500	7 5/8"	7 1/16"	4 1/8"	6 1/4"	12'	FLEX

Midway Gardens™

19520



	F	H	P	R	L	
19520	8"	7 11/16"	2 1/4"	3 1/2"	12'	FLEX

Heritage-Henredon Furniture Moulding

19540



	F	H	P	R	L	
19540	6 1/4"	4 1/8"	5"	7"	12'	FLEX

Harold C. Price House

19560



	F	H	P	R	L	
19560	5 1/2"	5 1/2"	1 3/4"	10"	12'	FLEX

Nathan G. Moore

19570



	F	H	P	R	L	
19570	8 1/8"	8"	1 1/2"	3"	12'	FLEX

Eastlake

19210

Eastlake Block

19218



	F	H	P	R	L	
19210	7 1/2"	4 1/2"	6"	8 1/4"	10'	FLEX
19218	8 1/8"	5 1/16"	6 5/16"	-	2 7/8"	FLEX

Pea Pod & Vine

19220

Pea Pod & Vine Block

19228



	F	H	P	R	L	
19220	8 1/2"	4 3/4"	7 1/8"	28 5/8"	12'	FLEX
19228	9"	4 7/8"	7 1/2"	-	3 3/8"	FLEX

Mille Fleur

19240

Mille Fleur Block

19248



	F	H	P	R	L	
19240	9 1/8"	4 3/4"	7 13/16"	10 3/8"	12'	FLEX
19248	10 1/8"	5 5/8"	8 3/8"	-	3 3/4"	FLEX



## Use Adhesive3 #33333

One tube per 60 ft. of moulding. Adhesive3 is specially formulated to help eliminate shrinking and cracking of joints and seams. (PL Premium Brand Adhesive is the only recommended substitute and is available at most retail locations.)



# Crown and Cornice Mouldings

## Versailles Crown

Used to make outside corners and straight runs to match and join 10760 and 10770

10750



	F	H	P	R	L
10750	9"	6 7/8"	7"	-	6' 6"

## Versailles Crown Corners

When cut, makes four inside corners. After mitered and glued, decorative section is 16" wide on each side.

10770



	F	H	P	R	L
10770	9"	6 7/8"	7"	3' 3"	2 pcs - 6' 6" ea

## Versailles Crown Center Piece

Used on center of wall.

10760



	F	H	P	R	L
10760	9"	6 7/8"	7"	6' 6"	6' 6"



### Products featured above:

- A. Acanthus Medallion (no hole)  
License Number 81031
- B. Versailles Crown Corners  
License Number 10770
- C. Versailles Crown  
License Number 10750
- D. Versailles Crown Center Piece  
License Number 10760
- E. Chelsea Rosette  
License Number 85000
- F. Denmark Chair Rail  
License Number 10620

# Crown and Cornice Mouldings

## Lighting Solutions

Illuminate opulence with Focal Point's Lighting Solutions line. Direct-light mouldings reveal design details and conceal structural distractions like cracks, pipes and cables. Combine light with our coves or mouldings for ambience-adding indirect light.


Products featured at right and below:



- A. Lighting Solutions Soffit  
License Number 10870
- B. Lighting Solutions Soffit  
License Number 10865



### Lighting Solutions Soffit


10860 | 10865




	F	H	P	R	L	
10860	8 1/2"	6"	6"	n/a	6' 6"	 UPS
10865	12 5/8"	7 7/8"	9 13/16"	n/a	6' 6"	 UPS

### Lighting Solutions Cove

10870



	F	H	P	R	L	
10870	8 7/8"	6 15/16"	5 9/16"	n/a	6' 6"	 UPS




# Polystyl™ Mouldings

## Affordable Details

Our low-density polymer Polystyl™ Mouldings offer economical elegance and simple installation with water-based adhesive caulk. No nails or screws needed.

### A Crown Mouldings



	F	H	P	R	L		
10020	2 3/4"	1 15/16"	1 15/16"	-	6' 6"	LD	UPS
10010	4 1/2"	3 1/8"	3 1/8"	-	6' 6"	LD	UPS
10000	6"	4 3/8"	4 1/8"	-	6' 6"	LD	UPS

### TI Crown Moulding



	F	H	P	R	L		
10180	7 5/8"	5 1/2"	5 5/16"	-	6' 6"	LD	UPS

### AT Crown Moulding



	F	H	P	R	L		
10030	5 1/2"	3 15/16"	3 3/4"	-	6' 6"	LD	UPS

### C Crown Moulding



	F	H	P	R	L		
10070	4"	3 1/8"	2 1/2"	2 9/16"	6' 6"	LD	UPS

### D Crown Moulding



	F	H	P	R	L		
10080	2 1/2"	1 15/16"	1 9/16"	-	6' 6"	LD	UPS

### K Crown Moulding



	F	H	P	R	L		
10210	1 3/8"	1 3/16"	1 1/16"	-	6' 6"	LD	UPS

### I Panel Moulding



	F	H	P	R	L		
10120	-	1 1/2"	5/8"	-	6' 6"	LD	UPS

### J Crown Moulding



	F	H	P	R	L		
10290	2 1/2"	1 3/4"	1 15/16"	-	6' 6"	LD	UPS

### SM Crown Moulding



	F	H	P	R	L		
10170	5 1/2"	4 1/8"	3 9/16"	-	6' 6"	LD	UPS

### TL Crown Moulding



	F	H	P	R	L		
10190	7 7/8"	6 1/16"	4 15/16"	-	6' 6"	LD	UPS



## CHAIR RAILS, CASINGS, FRIEZES & BASES

## Functional Flair

Our chair rails, casings and friezes will guard your walls while enhancing your decor.

Products featured at left:

A. Regency Niche  
License Number 91300

B. Belford Chair Rail  
License Number 11600

### Powell-Hallam House

16160



16160	H	P	R	L	
	2 13/16"	1 11/16"	1 5/16"	10'	

*Millwork* **FLEX**

### Trellis Frieze

11500



11500	H	P	R	L	
	5"	1 1/16"	2 5/16"	10'	

**FLEX**

### Rondel Chair Rail

11520



11520	H	P	R	L	
	3"	13/16"	1 1/2"	12'	

**FLEX**

### Greek Key Chair Rail

15315



15315	H	P	R	L	
	3 1/2"	3/4"	1 9/16"	12'	

**Pro** **FLEX**

15410	H	P	R	L	
	3 1/2"	3/4"	1 9/16"	8'	

**UPS** **FLEX**

### Linden Frieze

13040



13040	H	P	R	L	
	4"	3/4"	2"	12'	

**FLEX**

### Dentil Chair Rail

15305



15305	H	P	R	L	
	3 1/2"	7/8"	1 5/16"	12'	

**Pro** **FLEX**

15400	H	P	R	L	
	3 1/2"	7/8"	1 5/16"	8'	


**UPS** **FLEX**



# Chair Rails, Casings, Friezes & Bases

**Wythe House Chair Rail**

16570



	H	P	R	L	
16570	5 7/16"	1 3/4"	-	10'	

**Carter's Grove™ Chair Rail**

16580



	H	P	R	L	
16580	4 5/16"	2 3/16"	-	10'	

**Oatlands Bead and Reel**

17010



	H	P	R	L	
17010	3 1/16"	1 3/16"	2 13/16"	12'	

**Wilton Chair Rail**

15010



	H	P	R	L	
15010	3"	7/8"	-	12'	

**Rope Casing**


25120



	H	P	R	L	
25120	3 1/2"	13/16"	3/4"	12'	
25200	3 1/2"	13/16"	3/4"	8'	

**Denmark Chair Rail**

10620



	H	P	R	L	
10620	3 1/8"	3/4"	-	6' 6"	

**Rope Baseboard**

25080



	H	P	R	L	
25080	5 1/2"	13/16"	3/4"	8'	

**Rope Chair Rail**

15170



	H	P	R	L	
15170	3 1/4"	1 1/8"	3/4"	12'	
15165	3 1/4"	1 1/8"	3/4"	8'	

# Chair Rails, Casings, Friezes & Bases

**D'Evereux Frieze**

**13080**



<b>13080</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>		
	8 3/8"	1 1/8"	7 1/2"	12'		

*If used on ceiling, use square wood blocks at all corners.*



**Georgian Frieze**

**15205**



<b>15205</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>		
	7 1/2"	1 3/4"	7 1/8"	92 1/4"		



**Versailles Frieze**

**25230**




<b>25230</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>		
	4 7/8"	5/8"	11 1/4"	8'		



**Siena Frieze**

**15215**




<b>15215</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>		
	7 1/2"	1 3/4"	-	92 1/4"		



**Belford Chair Rail**

**11600**



<b>11600</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>	
	4 11/16"	1 1/2"	2"	12'	



**Covington Frieze**

**15080**



<b>15080</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>	
	8 3/4"	2 9/16"	-	12'	



**Peyton Randolph Chair Rail**

**16560**



<b>16560</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>		
	3 3/16"	1 1/8"	-	12'		



**Robert Carter House Chair Rail**

**16590**



<b>16590</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>		
	5 1/2"	1 13/16"	-	12'		



**Chatsworth Chair Rail/Panel Moulding**

**11800**



<b>11800</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>			
	2 1/8"	5/8"	-	8'			



**Classic Fluted Frieze**

**15220**




<b>15220</b>	<b>H</b>	<b>P</b>	<b>R</b>	<b>L</b>			
	7 1/2"	1 3/4"	1 1/2"	8'			



# Panel & Picture Mouldings

Embrace elegance with mouldings once used to hang pictures. Now these wall accents fine-tune your style whether Victorian or present-day.

Products featured at right:  
A. Panel Moulding  
License Number 10590



## PANEL & PICTURE MOULDINGS

### SYSTEM A

#### Panel Moulding

10590



	H	P	R	L	UPS
10590	1 1/2"	11/16"	-	6 6"	

#### Panel Corners


10399 | 10299



	L	H	Unit	UPS
10399 – Small Corner	5 3/4"	5 3/4"	4/set	
10299 – Large Corner	7 7/8"	7 7/8"	4/set	

#### Acanthus Paneling

10499 | 10199



	L	H	P	Unit
10499 – Panel Center	9 1/2"	1 1/2"	4 1/8"	2/set
10199 – Panel Corner	7 7/8"	7 7/8"	-	4/set

UPS

Four Panel Moulding Systems available:  
Panel Mouldings in this section match corresponding corners – Micro Panel Moulding #10820 should be ordered with Micro Corners 10824 or 10825 for example.

# Panel & Picture Mouldings

## SYSTEM B

### Chatsworth Chair Rail/Panel Moulding

11800





	H	P	L	
11800	2 1/8"	5/8"	8'	 

### Chatsworth Corner Panel

11810





	L	H	Unit	
11810	11 5/8"	11 5/8"	4/set	 

### Bellflower Corner Panel

11820



	L	H	Unit	
11820	11 13/16"	11 13/16"	4/set	 

## SYSTEM C

### Micro Panel Moulding #2

10820



	H	P	R	L	
10820	13/16"	3/8"	-	6' 6"	

Use with 10824 or 10825

### Micro Corners 2

10824 | 10825



	L	H	Unit	
10824	3 1/8"	3 1/8"	4/set	
10825	5 1/8"	5 1/8"	4/set	



## SYSTEM D

### Micro Panel Moulding #3

10830



	H	P	R	L	
10830	7/8"	1/2"	-	6' 6"	

Use with 10833, 10834, 10836 or 10837

### Micro Corners 3

10833 | 10834



	L	H	Unit	
10833	3 1/8"	3 1/8"	4/set	
10834	5 1/8"	5 1/8"	4/set	



### Micro Corners 3

10836 | 10837



	L	H	Unit	
10836	3 1/8"	3 1/8"	4/set	
10837	5 1/8"	5 1/8"	4/set	



L (length)



H (height)