

# COLUMN CAPITALS



	A	B	C
R-CAPIT-C-8"	6 <sup>1</sup> / <sub>2</sub> "	9 <sup>1</sup> / <sub>4</sub> "	11 <sup>1</sup> / <sub>2</sub> "
R-CAPIT-C-10"	8 <sup>1</sup> / <sub>8</sub> "	10 <sup>7</sup> / <sub>8</sub> "	14"
R-CAPIT-C-12"	10 <sup>1</sup> / <sub>4</sub> "	13 <sup>3</sup> / <sub>8</sub> "	19 <sup>1</sup> / <sub>4</sub> "



	A	B	C
R-CAPIT-G-8"	6 <sup>5</sup> / <sub>8</sub> "	3 <sup>1</sup> / <sub>2</sub> "	7 <sup>1</sup> / <sub>4</sub> "x7 <sup>1</sup> / <sub>4</sub> "
R-CAPIT-G-10"	8 <sup>5</sup> / <sub>8</sub> "	4 <sup>7</sup> / <sub>8</sub> "	10 <sup>1</sup> / <sub>4</sub> "x9 <sup>3</sup> / <sub>4</sub> "
R-CAPIT-G-12"	10 <sup>1</sup> / <sub>4</sub> "	5 <sup>1</sup> / <sub>2</sub> "	12 <sup>1</sup> / <sub>4</sub> "x12 <sup>1</sup> / <sub>4</sub> "



	A	B	C
R-CAPIT-M-8"	6 <sup>1</sup> / <sub>2</sub> "	10 <sup>1</sup> / <sub>4</sub> "	14 <sup>1</sup> / <sub>2</sub> "
R-CAPIT-M-10"	8 <sup>1</sup> / <sub>4</sub> "	11 <sup>1</sup> / <sub>2</sub> "	14 <sup>5</sup> / <sub>8</sub> "
R-CAPIT-M-12"	10 <sup>1</sup> / <sub>4</sub> "	12 <sup>1</sup> / <sub>8</sub> "	17 <sup>1</sup> / <sub>8</sub> "



	A	B	C
R-CAPIT-R-8"	6 <sup>5</sup> / <sub>8</sub> "	3"	7 <sup>3</sup> / <sub>4</sub> "x7 <sup>1</sup> / <sub>2</sub> "
R-CAPIT-R-10"	8 <sup>1</sup> / <sub>8</sub> "	4 <sup>7</sup> / <sub>8</sub> "	9 <sup>3</sup> / <sub>4</sub> "x10 <sup>3</sup> / <sub>4</sub> "
R-CAPIT-R-12"	10 <sup>1</sup> / <sub>8</sub> "	4 <sup>3</sup> / <sub>4</sub> "	12 <sup>3</sup> / <sub>8</sub> "x13 <sup>1</sup> / <sub>4</sub> "



	A	B	C
R-CAPIT-T-8"	6 <sup>3</sup> / <sub>8</sub> "	7 <sup>3</sup> / <sub>4</sub> "	10 <sup>5</sup> / <sub>8</sub> "
R-CAPIT-T-10"	8 <sup>1</sup> / <sub>8</sub> "	9 <sup>3</sup> / <sub>4</sub> "	13 <sup>1</sup> / <sub>2</sub> "
R-CAPIT-T-12"	10 <sup>1</sup> / <sub>4</sub> "	11 <sup>3</sup> / <sub>8</sub> "	16 <sup>3</sup> / <sub>8</sub> "




	A	B	C
R-CAPIT-S-8"	6 <sup>1</sup> / <sub>2</sub> "	2 <sup>7</sup> / <sub>8</sub> "	9 <sup>1</sup> / <sub>2</sub> "
R-CAPIT-S-10"	8 <sup>1</sup> / <sub>4</sub> "	3 <sup>1</sup> / <sub>2</sub> "	13"
R-CAPIT-S-12"	10 <sup>1</sup> / <sub>8</sub> "	4 <sup>1</sup> / <sub>8</sub> "	16 <sup>1</sup> / <sub>2</sub> "

Resinart East, Inc. Column Material has been tested for smoke development and flame spread under test standard: ASTM E84. Also, all Resinart Columns have been tested for load bearing capability. Documentation available upon request.

**WARRANTEES**

Resinart East, Inc. warranties all products to be free from defects in material and workmanship for a period of one year from date of purchase. In the event the material received is defective, Resinart East, Inc. will replace the material at no charge to the customer or refund the purchase price.

## How to Order Resinart capitals:




**A**=Base **B**=Height  
**C**=Abacus

To assure a proper fit simply measure the top diameter of your column (see "A" in diagram) and match it to the bottom diameter of the capitals.

THE PROFESSIONALS CHOICE

# RESINART COLUMNS






Round

Fluted

Square

DURAFLEX	FITS COLUMN DIAMETER		
	8"	10"	12"
LOAD LIMIT	12,000 lbs. MAX	16,000 lbs. MAX	20,000 lbs. MAX

- Load Bearing
- Will not rot, bow, or crack, and is substantially more impact resistant than wood.
- No priming necessary for painting.
- Quick and easy to install.
- Maintenance free.
- Tapered in the Greek Tradition.



- A** Bottom Diameter
- B** Top Diameter
- C** Ring
- D** Neck to 1st Ring
- E** Neck Height
- F** Overall Height
- G** Neck Diameter
- H** Ring
- I** Taper starts from bottom

## SQUARE COLUMNS

	COLUMN SIZE	ACTUAL WIDTH	CAP WIDTH	CAP HEIGHT	BASE WIDTH	BASE HEIGHT	TOTAL LENGTH	CHAMFER STARTS
R-SQCOL-S-8 x 8,10,12	8" sq.	7 <sup>3</sup> / <sub>4</sub> "	10"	2 <sup>1</sup> / <sub>4</sub> ,2 <sup>1</sup> / <sub>2</sub> ,3"	10"	3 <sup>1</sup> / <sub>2</sub> ,4,4 <sup>1</sup> / <sub>2</sub> "	8,10,12'	16"
R-SQCOL-S-10 x 8,10,12	10" sq.	9 <sup>3</sup> / <sub>4</sub> "	12"	2 <sup>1</sup> / <sub>4</sub> ,2 <sup>1</sup> / <sub>2</sub> ,3"	12"	3 <sup>1</sup> / <sub>2</sub> ,4,4 <sup>1</sup> / <sub>2</sub> "	8,10,12'	17"
R-SQCOL-S-12 x 8,10,12	12" sq.	11 <sup>3</sup> / <sub>4</sub> "	14"	2 <sup>1</sup> / <sub>4</sub> ,2 <sup>1</sup> / <sub>2</sub> ,3"	14"	3 <sup>1</sup> / <sub>2</sub> ,4,4 <sup>1</sup> / <sub>2</sub> "	8,10,12'	18"

## ROUND COLUMNS/FLUTED


	COLUMN SIZE	A	B	C	D	E	F	G	H	I
R-COLUM-S-8 x 8	8" x 8'	7 <sup>3</sup> / <sub>4</sub> "	6 <sup>1</sup> / <sub>4</sub> "	1"	1 <sup>1</sup> / <sub>2</sub> "	4 <sup>7</sup> / <sub>8</sub> "	96"	6 <sup>1</sup> / <sub>4</sub> "	3 <sup>3</sup> / <sub>8</sub> "	33"
R-COLUM-S-8 x 10	8" x 10'	7 <sup>3</sup> / <sub>4</sub> "	6 <sup>1</sup> / <sub>4</sub> "	1"	1 <sup>1</sup> / <sub>2</sub> "	4 <sup>7</sup> / <sub>8</sub> "	120"	6 <sup>1</sup> / <sub>4</sub> "	3 <sup>3</sup> / <sub>8</sub> "	42"
R-COLUM-S-10 x 8	10" x 8'	9 <sup>3</sup> / <sub>4</sub> "	8"	1"	1 <sup>1</sup> / <sub>2</sub> "	5 <sup>1</sup> / <sub>2</sub> "	96"	8"	3 <sup>3</sup> / <sub>8</sub> "	33"
R-COLUM-S-10 x 10	10" x 10'	9 <sup>3</sup> / <sub>4</sub> "	8"	1"	1 <sup>1</sup> / <sub>2</sub> "	5 <sup>1</sup> / <sub>2</sub> "	120"	8"	3 <sup>3</sup> / <sub>8</sub> "	42"
R-COLUM-S-10 x 12	10" x 12'	9 <sup>3</sup> / <sub>4</sub> "	8"	1"	1 <sup>1</sup> / <sub>2</sub> "	5 <sup>1</sup> / <sub>2</sub> "	146"	8"	3 <sup>3</sup> / <sub>8</sub> "	48"
R-COLUM-S-12 x 8	12" x 8'	11 <sup>3</sup> / <sub>4</sub> "	10"	1"	1 <sup>1</sup> / <sub>2</sub> "	6"	96"	10"	3 <sup>3</sup> / <sub>8</sub> "	33"
R-COLUM-S-12 x 10	12" x 10'	11 <sup>3</sup> / <sub>4</sub> "	10"	1"	1 <sup>1</sup> / <sub>2</sub> "	6"	120"	10"	3 <sup>3</sup> / <sub>8</sub> "	42"
R-COLUM-S-12 x 12	12" x 12'	11 <sup>3</sup> / <sub>4</sub> "	10"	1"	1 <sup>1</sup> / <sub>2</sub> "	6"	140"	10"	3 <sup>3</sup> / <sub>8</sub> "	48"

## TUSCAN CAP & BASE



Tuscan - U-Cap 6" to 18"

	BASE	COL. DIA.	HT.
R-TUSCN-S-8CAP	9 <sup>3</sup> / <sub>8</sub> "	8"	2 <sup>3</sup> / <sub>4</sub> "
R-TUSCN-S-10CAP	11 <sup>7</sup> / <sub>8</sub> "	10"	3 <sup>1</sup> / <sub>2</sub> "
R-TUSCN-S-12CAP	14 <sup>1</sup> / <sub>8</sub> "	12"	4"



	BASE	COL. DIA.	HT.
R-TUSCN-S-8BAS	10 <sup>3</sup> / <sub>4</sub> "	8"	4 <sup>1</sup> / <sub>4</sub> "
R-TUSCN-S-10BAS	13 <sup>1</sup> / <sub>4</sub> "	10"	5 <sup>1</sup> / <sub>4</sub> "
R-TUSCN-S-12BAS	16 <sup>1</sup> / <sub>2</sub> "	12"	6"

## ATTIC BASE

	BASE	COL. DIA.	HT.
R-MSAT-S-8"	10 <sup>7</sup> / <sub>8</sub> "	8"	6"
R-MSAT-S-10"	12 <sup>3</sup> / <sub>4</sub> "	10"	7"
R-MSAT-S-12"	15 <sup>1</sup> / <sub>2</sub> "	12"	8"

